



Wireless Drive-Thru Audio System

Operating Instructions

HM Electronics, Inc.
14110 Stowe Drive
Poway, CA 92064 USA

Phone: 1-800-848-4468
Fax: 858-552-0172

HME# 400G636 Rev A 12/21/09

Table of Contents

ion IQTM EQUIPMENT	1
Base Station.....	2
Front Panel.....	2
Rear and Side Panels.....	3
HEADSET.....	4
Features and Controls.....	4
How to Wear the Headset.....	4
How to Use the Headset Controls.....	5
Headset Registration.....	5
Battery Removal and Replacement.....	8
Battery Charger.....	9
ion IQTM OPERATION	10
Changing Language of Headset Cues.....	10
Obtaining Headset Status.....	10
Single-Lane Operation.....	11
Dual-Lane Operation.....	12
Tandem Operation.....	13
Internal Communication.....	13
Speed-Team Operation.....	14
Message Center Operation.....	15
Customer Message Settings.....	17
Reminder Message Settings.....	21
Alert Message Settings.....	25
Schedule Times.....	30
Volume Adjustments.....	31
Wired Backup System Operation.....	32
Vehicle Detection.....	33
Store Settings.....	34
PC Navigation.....	41
EQUIPMENT CARE AND CLEANING	42
Handling the Equipment Properly.....	42
Cleaning the Equipment.....	42
IN CASE OF PROBLEMS	43
Troubleshooting.....	43
Service Call.....	44
Base Station Internal Controls and Indicators.....	45
Diagnostics.....	46
EQUIPMENT SPECIFICATIONS	47
FCC NOTICE	48

Figures and Diagrams

Figure 1. ion IQ TM standard equipment.....	1
Figure 2. Base station front panel features.....	2
Figure 3. Base station rear panel features.....	3
Figure 4. Headset controls.....	4
Figure 5. Correct wearing of the headset.....	4
Figure 6. Belt-pac battery-release latch.....	8
Figure 7. Headset battery-release latch.....	8
Figure 8. Batteries in charger.....	9
Figure 9. Typical tandem drive-thru.....	13
Figure 10. Wired backup switches on bottom of base station.....	32
Figure 11. Base station internal features.....	45

The Headset provides basic operating cues in Spanish and French, as follows. Refer also to the Changing Languages instructions on [page 10](#).

Español

El COM6000BP proporciona información que indica el estado del funcionamiento del mismo en español como es: **Unidad #, Batería cargada, Batería semi-cargada, Batería baja, Línea uno, Línea dos, Fuera de alcance, Reemplazar batería y Unidad desactivado.**

Para cambiar el idioma de la información que se escucha en la diadema, de inglés a español, siga los siguientes pasos: Oprima y mantenga presionado el botón “A1”, así como el botón para reducir el volumen “▼” y el botón para encender el comunicador “PWR” al mismo tiempo, hasta que el comunicador se encienda.

Français

COM6000BP fournit les sélections de fonctionnement fondamentales suivantes en français: **Ceinture-sac #, Fonction inactive, Batterie charge, Batterie demi-charge, Batterie basse-charge, Voie un, Voie deux, hors d'entente, Remplace batterie et Ceinture-sac inactive.**

Pour changer les indications de l'anglais au français, appuyer et tenir le “A1” et le volume en bas “▼” en même temps, tout en appuyant sur le bouton d'allumage “PWR”.

HM Electronics, Inc. is not responsible for equipment malfunctions due to erroneous translation of its installation and / or operating publications from their original English versions.

Illustrations in this publication are approximate representations of the actual equipment, and may not be exactly as the equipment appears.

ion|IQ™ EQUIPMENT

The ion|IQ™ is an audio system primarily for use at quick-service restaurants. The equipment shown below is standard with the ion|IQ™. Optional equipment can be ordered from your local dealer.

NOTE:

Equipment quantities vary, depending on individual store needs at time of purchase. Additional equipment can be ordered from the list below.



Base Station



Odyssey IQ




COM6000BP



OPTIONAL EQUIPMENT

Equipment	Model Number
Belt-Pac	COM6000BP
Belt	None
Odyssey IQ All-In-One Headset	HS6000
Wireless Headset (listen only)	HS6000L
Battery for Odyssey IQ	BAT41
Headset	HS12
Headset, Over-the-Ear	M220
Headset Earmuff	None
Headset Earpiece Cover (disposable)	None
Headset Interface	HSI6000
Telephone Interface	TI6000
Vehicle Detector Board	VDB102
Vehicle Detector Board (with relay)	VDB102R
Vehicle Detector Loop (underground)	VDL100
Low-Profile Speaker	SP2500LP
Ceiling Speaker	MM100
Microphone	DM4
Mode Switch (dual lane)	MS10
Remote Speed Team Switch	SW2
Switcher Circuit Board	None
Antenna Coverage Extension Kit	EC10
Extended Coverage Antenna Kit	EC20
Remote Antenna Kit (with 6 ft / 1.83 meter cable)	ANT20-6
Remote Antenna Kit (with 30 ft / 9.14 meter cable)	ANT20-30



Battery Charger



Battery



Microphone



Speaker

Figure 1. ion|IQ™ standard equipment

Base Station

All functions of the drive-thru audio system are channeled through the base station. It is the electronic heart of the ion|IQ™.

External base station features are shown in Figures 2 and 3. Internal features are shown in [Figure 11](#).

Front Panel





Figure 2. Base station front panel features

- The **display screen** is where all menu selections will be seen for installer setups and routine operation options. The **STATUS** display will be shown on the base station until you press any of the buttons to select another display.

NOTE:

The **STATUS** display will turn off (sleep) if there is no button activity. Pressing any button will turn it back on (wake it up).



- The **menu-select buttons** are used to make selections from the menu on the display screen.
- The **Help button** can be pushed to obtain information needed in case of problems with the ion|IQ™.
- The **Back button** can be pushed to go back to the previous menu display.
- The **activity indicators** light up as follows:

Above the line - Lane 1 activity (single or dual-lane operations)

A1 lights up when the A button is pushed on any headset in single-lane operations, or on any Lane 1 headset in dual-lane operations.

B1 lights up when the B button is pushed on any headset in single-lane operations, or on any Lane 1 headset in dual-lane operations.

The **car above the line** lights up when a car is present at the menu board in single-lane operations, or at the Lane 1 menu board in dual-lane operations.

Below the line - Lane 2 activity (dual lane operations only)

A2 lights up when the A button is pushed on any Lane 2 headset.

B2 lights up when the B button is pushed on any Lane 2 headset.

The **car below the line** lights up when a car is present at the Lane 2 menu board.

Rear and Side Panels




Figure 3. Base station rear panel features

- When both of the **cabinet latches**, on top of the cabinet are pressed down at the same time, the cabinet can be opened by pulling forward and down.
- The **antenna connectors** are for screw-mounting the enclosed antennas.
- The four **screwholes** are used to mount the base station on the wall.
- The **reset switch**, on the side of the base station, is used to restart the base station.

HEADSET

Features and Controls




Figure 4. Headset controls

How to Wear the Headset

- Wear the headset with the microphone on your right or left side next to your mouth.
- Adjust the headband and microphone boom as needed.
- If you are using a belt-pac with headset, clip the belt-pac to your belt or waistband on either your right or left side. Clip the clothing clips on the headset cable to the back of your shirt and collar.
- If you are using an Odyssey IQ All-In-One Headset, put the headset on your head with the headset band behind your neck.




Figure 5. Correct wearing of the headset

How to Use the Headset Controls

The headset control buttons will activate when pressed firmly. Use your fingertips, not your fingernails, to press the buttons. Refer to Figure 4 on page 4.

Power On/Off

- **Power On** — Press and release the PWR (power) button. A voice message in the earpiece will say “belt-pac #, battery full/half/low” and the red power lights next to the A1 and A2 buttons on the belt-pac will go on. After a short time, one light will go off and the other will change to green. The voice message will then say “Lane 1 (or 2).” The green light indicates the headset is ready to use. In dual-lane operations, a green light next to A1 indicates ready on Lane 1 and a green light next to A2 indicates ready on Lane 2.
- **Power Off** — Press and hold the PWR button for about two seconds. A voice message in the earpiece will say “belt-pac off” or “headset off,” and the power light will go off.

Volume Up/Down

- **Volume Up Adjustment** — Press and release the volume-up ▲ button. Each time you press the button you will hear a higher pitch beep in the earpiece as the volume increases. When you reach maximum volume, you will hear “maximum.” If you continue holding the volume-up ▲ button, “maximum” will keep repeating until you release the button.
- **Volume Down Adjustment** — Press and release the volume-down ▼ button. Each time you press the button you will hear a lower pitch beep in the earpiece as the volume decreases. When you reach minimum volume, you will hear a low-pitched double beep. If you press and hold the volume-down ▼ button, you will hear repeating beeps, decreasing in pitch until the volume reaches minimum. Then you will hear low-pitched double beeps repeating until you release the volume-down ▼ button.

Headset Registration

During installation of the ion|IQ™, each headset was registered for use with the base station. The base station thereby recognizes all headsets registered to it when their power is on, and will be able to tell the difference between them and other electronic equipment operating on similar frequencies.

A maximum of 15 headsets can be registered. If one is replaced, you must register the new one before you use it. When a headset is replaced, the old one remains in memory. If the maximum number of 15 (in memory) is exceeded, the base station display will tell you that 0 more headsets can be registered. If this happens, you may either clear all inactive headsets or clear all current registrations. If you clear all inactive headsets, you can initiate the new registration. If you clear all current registrations, you must re-register all active headsets. Each active headset is registered the same way, one at a time.

NOTE:


All currently registered headsets must be turned on, or they will be unregistered when you clear inactive headsets.

Register each headset as follows:


- Be certain all headsets to be registered are turned off and the base station power is on. Other headsets can be on or off.
- On the base station **STATUS** display, press the **Menu** button.

NOTE:

Headsets must be within 6 feet (1.83 meters) of the base station while being registered.



- On the **MAIN MENU**, press the **Register** button.



NOTE:

You will be given a warning and allowed to quit or continue before registrations are cleared.

- If you press the **Clear Inactive** button, you will unregister any headsets that are not turned on.
- If you press the **Clear All** button, you will unregister all headsets that are registered to the base station.



- To register headsets, press the **Register Headset** button on the **REGISTRATION** display.

- On the **TO REGISTER HEADSETS** display, follow the instructions in the box.



For each headset to be registered:

- Turn OFF the headset.
- Press/hold the B button on the headset while pressing its power button.
- Release both buttons.
- If you are registering only one headset, press the **Register Single** button on the base station **TO REGISTER HEADSETS** display.
- If you are registering more than one headset, press the **Register Multi** button on the **TO REGISTER HEADSETS** display, and continue registering the remaining ones.

When each registration is successfully completed:

- The ID number assigned to this headset will be shown. ID numbers are assigned sequentially as 0 thru 9, A, b, C, d and E.



- When you have finished registering headsets, press the **Back** button to exit the registration mode. You can press the **Back** button repeatedly until you return to the **MAIN MENU** or **STATUS** display.
- The power light on the headset will remain on steady green.

If you have any problems registering the headsets:

In the USA, call HME Customer Support at 1-800-848-4468.

Outside the USA, call your local HME representative for assistance.

Battery Removal and Replacement

COM6000BP Belt-pac Batteries —

To change batteries:

If a battery is weak when Belt-pac power is turned on, a voice in the earpiece will say “Battery low.” If a battery becomes weak during operation, a voice in the earpiece will say “Change battery.” When this happens, take the Belt-pac out of its pouch and slide the battery-release latch in the direction of the arrow. Pull up on the end of the battery near the latch and lift it out of the Belt-pac, or turn the Belt-pac over and catch the battery in your hand.



Figure 6.
Belt-pac battery-release latch

To replace batteries:

When replacing a battery in the Belt-pac, place the end of the battery with the metal contacts into the battery holder on the Belt-pac, in the same position as the battery you removed. Press the top of the battery carefully into the battery holder until it snaps into the latch.

Odyssey IQ Headset Batteries —

To change batteries:

When a battery becomes weak, a voice in the Headset will say “Change battery.” When this happens, remove the battery from the Headset by carefully sliding the battery-release latch and lifting the battery out.




Figure 7. Headset battery-release latch

To replace batteries:

When replacing a battery in the Headset, place the end of the battery with the metal contacts into the battery holder on the Headset, in the same position as the battery you removed. Press the top of the battery carefully into the battery holder until it snaps in place under the battery-release latch.

Recharge batteries according to the instructions on page 9.

Battery Charger

Up to four batteries can be charged in the charger at the same time. Charging time is approximately 2.5 hours. The battery status lights next to each charging port are explained below. Up to six fully charged batteries can be stored in the battery storage ports.

- A yellow light stays on steady next to each charging port while the port is empty.
- Insert a battery in one of the four charging ports until it clicks in place.
- If a yellow light is on steady next to a battery in a charging port, it means CHARGE FAILED. Follow the diagnostic instructions on the side of the battery charger.
- If a yellow light is flashing next to a battery in a charging port, it indicates CHARGE PENDING, which means the battery is too hot. Lower the room temperature or move the charger to a cooler area.
- A red CHARGING light will stay on next to a battery in a charging port while the battery is charging.
- A green READY light will go on next to a battery in a charging port when the battery is fully charged.
- Store fully charged batteries in the storage ports.

CAUTION:
Do not remove batteries from the charger until the green READY light is lit, or the charger will reset and the charge cycle will begin




Figure 8. Batteries in charger

ion/IQ™ OPERATION

A full-duplex system supports HF, AHF and PTT operation. Communication can be transmitted and received at the same time, as in a normal telephone conversation. In the AHF mode, transmission and reception are activated automatically when a customer drives into the drive-thru lane. In the HF mode, transmission and reception are activated by touching and releasing one of the A buttons on the headset. In the PTT mode, one of the A buttons on the headset must be held while the operator is talking to the customer. A half-duplex system only supports the PTT mode. One of the A buttons on the headset must be held while the operator speaks to the customer. The customer's voice will not be heard while the operator is transmitting.

In single lane operations, when a customer arrives in the drive-thru lane, you will hear a single beep in the headset.

In dual-lane operations, when a customer arrives in Lane 1, you will hear a single beep in the headset; when a customer arrives in Lane 2, you will hear a double beep.

Refer to the instructions on the following pages for single-lane or dual-lane stores.

Changing Language of Headset Cues

To change the language of the cues heard in the headset from English to Spanish/French and back to English, with the headset power off, press and hold the volume-down ▼ button and the A1 button while you press the power PWR button. The language of the cues heard in the headset earpiece will change when the power goes on.

Obtaining Headset Status

To obtain headset status, with the headset power off, press and hold the volume-down ▼ button and the A2 button while you press the power PWR button. You will hear the status message in the headset earpiece when the power goes on.

Single-Lane Operation

Hands-Free (HF) Mode

- With the power off, press and hold the volume-up ▲ and B buttons while you press and release the PWR button to turn the power on in the HF mode. The headset will remember this setting.
- As a customer enters the drive-thru lane, you will hear an alert tone (single beep) in your headset, and you will be able to hear the customer at the speaker post or menu board.
- Touch and release the A1 or A2 button to speak and listen to the customer.
- Touch and release the A1, A2 or B button to end communication with the customer.
- Touch and release the A1 or A2 button if you want to speak to the customer again.
- Use the volume-up ▲ and down ▼ buttons to adjust the customer's voice level in your headset if necessary.
- If a customer drives away from the speaker post or menu board, the headset will stop transmitting.

Auto Hands-Free (AHF) Mode

- With the power off, press and hold the volume-up ▲ and A1 buttons while you press and release the PWR button to turn the power on in the AHF mode.
- As a customer enters the drive-thru lane, you will hear an alert tone (single beep) in your headset, and you will be able to hear the customer at the speaker post or menu board.
- Speak and listen to the customer without pressing any buttons.
- Touch and release the A1, A2 or B button to end communication with the customer.
- Touch and release the A1 or A2 button if you want to speak to the customer again.
- Use the volume-up ▲ and down ▼ buttons to adjust the customer's voice level in your headset if necessary.
- If a customer drives away from the speaker post or menu board, the headset will stop transmitting.

Push-To-Talk (PTT) Mode

- With the power off, press and hold the volume-down ▼ and B buttons while you press and release the PWR button to turn the power on in the PTT mode. The headset will remember this setting.
- As a customer enters the drive-thru lane, you will hear an alert tone (single beep) in your headset, and you will be able to hear the customer at the speaker post or menu board.
- Touch and hold the A1 or A2 button to speak to the customer. Release when finished.
- Use the volume-up ▲ and down ▼ buttons to adjust the customer's voice level in your headset if necessary.

NOTE:

Only one headset operator at a time can use the auto hands-free feature, and this feature must also be enabled on the base station. If a headset is turned off while in the AHF mode, it will automatically be reset for its previous operating mode.

Dual-Lane Operation

NOTE:

If you have an **optional MS10 Mode Switch**, placing the switch in the *Non-Dedicated* position allows headset operators to hear alert tones when a customer arrives in either lane. Placing the switch in the *Dedicated* position allows an operator for either lane to hear only alert tones for customers arriving in his/her own lane.

NOTE:

In each lane, only one headset operator at a time can use the auto hands-free feature. If an operator attempts to configure a second headset, “System busy” will be heard in his/her headset.

When operating in the AHF mode, changing lanes is not possible. If a headset is turned off while in the AHF mode, it will automatically be reset for its previous operating mode.

In a dual-lane operation, there are two lanes, with one order point in each lane.

Hands-Free (HF) Mode

- With the headset power off, press and hold the volume-up ▲ and B buttons while you press and release the PWR button to turn the power on in the HF mode. The headset will remember this setting.
- As a customer enters a drive-thru lane, you will hear an alert tone in your headset (single beep for lane 1, double beep for lane 2), and you will be able to hear the customer at the speaker post or menu board if that lane is selected.
- Touch and release the A1 button for Lane 1 or A2 for Lane 2, to speak and listen to the customer.
- Touch and release the A1, A2 (depending on lane) or B button to end communication with the customer.
- Touch and release the A1 button for Lane 1 or A2 for Lane 2, to speak to the customer again.
- Use the volume-up ▲ and down ▼ buttons to adjust the customer’s voice level in your headset if necessary.
- To change lanes, touch and release the opposite A button.
- If a customer drives away from the speaker post or menu board, the headset will stop transmitting.

Auto Hands-Free (AHF) Mode

- For Lane 1 operation, with the power off, press and hold the volume-up ▲ and A1 buttons while you press and release the PWR button to turn the power on in the AHF mode.
- For Lane 2 operation, with the power off, press and hold the volume-up ▲ and A2 buttons while you press and release the PWR button to turn the power on in the AHF mode.
- As a customer enters a drive-thru lane, you will hear an alert tone in your headset (single beep for lane 1, double beep for lane 2), and you will be able to hear the customer at the speaker post or menu board if that lane is selected.
- Speak and listen to the customer without pressing any buttons.
- Touch and release the A1, A2 (depending on lane) or B button to end communication with the customer.
- Touch and release the A1 button for Lane 1 or A2 for Lane 2, to speak to the customer again.
- Use the volume-up ▲ and down ▼ buttons to adjust the customer’s voice level in your headset if necessary.
- If a customer drives away from the speaker post or menu board, the headset will stop transmitting.

Push-To-Talk (PTT) Mode

- With the headset power off, press and hold the volume-down ▼ and B buttons while you press and release the PWR button to turn the power on in the PTT mode. The headset will remember this setting.
- As a customer enters a drive-thru lane, you will hear an alert tone in your headset (single beep for lane 1, double beep for lane 2), and you will be able to hear the customer at the speaker post or menu board if that lane is selected.
- Touch and hold the A1 button to speak to a customer in Lane 1, or A2 to speak to a customer in Lane 2.
- Release the A1 or A2 button to hear the customer.
- Use the volume-up ▲ and down ▼ buttons to adjust the customer’s voice level in your headset if necessary.

Tandem Operation

Tandem is a special case of dual-lane operation in which a customer arriving at Order Point #2 can be given a “Please pull forward” message if no customer is present at Order Point #1. Headset operation is the same as described for dual-lane operation.

NOTE:

In Tandem operation, if Order Taker #2's headset is set in the Auto Hands-Free mode, the “Please pull forward” message will not be played at Order Point #2. If necessary, Order Taker #2 will have to ask the customer at Order Point #2 to pull forward. If a headset is turned off while in the AHF mode, it will automatically be reset for its previous operating mode.




Figure 9. Typical tandem drive-thru

Internal Communication


To communicate internally with other headset operators, press and hold the B button while talking. Release when finished. In single-lane operations, up to four headset operators can have conference-call type communication by all pressing the B button. Everyone pressing the B button will hear each other without interference.

In dual-lane operation, if your system was set up for “Split-B,” internal communication will be heard only by headset operators in your lane. If your system was set up for “Combined-B” operation, internal communication will be heard by all headset operators in both lanes. In dual-lane operation, up to three headset operators can have conference-call type communication by all pressing the B button. Everyone pressing the B button will hear each other without interference. If a car arrives in a lane while internal communication is taking place, priority will be given to the respective A channel for customer communication, which will reduce the number of internal communication channels available.

Speed-Team Operation

Speed team operation is used during high-volume times. An order taker wearing a headset relays orders from outside into the store, using button A1, A2 or B.


To start speed-team operation, you must press the **Menu** button on the base station **STATUS** display, and then press the **Speed Team** button on the **MAIN MENU**.



On the **SPEED TEAM** display, press the **Turn Speed Team** button, and select **On**. To change back to normal operation, return to the **SPEED TEAM** display and press the **Turn Speed Team** button, and select **Off**.

CAUTION:

If Speed Team is On, normal base station functions will be disabled. This includes car detection tones and certain automatic functions.



If you have an external speed-team switch, you can select **Ext** on the **SPEED TEAM** display, and then use the optional remote speed-team switch to go in and out of speed-team operation.

To save the setting, press the **Back** button one or more times.

Message Center Operation

HINT!

Before continuing, it is important to consider all the possible time periods during which any of the Message Center messages need to be played in your store. Up to 12 time periods can be set up. You can use the Message Center Settings Worksheet at the back of this manual. When you have determined all the time periods needed, go to the Schedule Times section of these instructions to set up the time periods for your store before continuing with the Message Center setups. The current time and date, and store open and close times should also be set before other Message Center setups.

The Message Center is a central point at which messages can be set up to be triggered by various events during designated time periods, to be sent to customers at the speaker post or to crew members via headsets or ceiling speakers.

Some messages are pre-named and pre-recorded. All messages can be customized to meet your specific requirements. The three types of messages are described below. The table on the next page shows the names and contents of factory pre-set messages. Following the table are detailed instructions of how to set up your Message Center.

At the back of this manual you will find a Message Center Quick Start Guide for planning your message settings.

Customer Greeter messages

Customer Greeter messages are heard by the customer at the speaker post. They are typically used to greet customers and inform them of promotional items. Customer Greeter messages are pre-named but not pre-recorded, with the following exceptions; the Store Closed message and Pull Forward message (only for tandem drive-thrus) are pre-recorded. All Customer Greeter messages can be renamed and recorded or re-recorded to meet your store needs.

Reminder messages

Reminder messages are heard by crew members in their headsets to remind them when routine tasks need to be done. There are 12 pre-named and pre-recorded Reminder messages that can be named and recorded to meet your store needs. There are also 3 “Empty” messages that can be named and recorded as needed. Reminder messages can be sent to all headsets or targeted only to designated headsets.

Alert messages

Alert messages are heard by crew members in their headsets to let them know something that requires attention, such as a door being left open or a customer arriving in the store. Alert messages can be sent to all headsets or targeted only to designated headsets. There are 4 pre-named and pre-recorded Alert messages that can be renamed and re-recorded to meet your store needs. There are also 16 “Empty” messages, of which 1 additional message in single-lane operations, or 2 additional messages in dual-lane operations can be recorded and used for Alert messages.

Customer Greeter messages are triggered by detection of vehicles in the drive-thru lane, plus time and day.


Reminder messages are triggered by time and day only.

Alert messages are triggered by input signals, plus time and day or Network events.

MESSAGE CENTER MESSAGES		
	NAME	CONTENT
CUSTOMER GREETER	All Day 1	Not pre-recorded.
	All Day 2	Not pre-recorded.
	Breakfast 1	Not pre-recorded.
	Breakfast 2	Not pre-recorded.
	Lunch 1	Not pre-recorded.
	Lunch 2	Not pre-recorded.
	Snack 1	Not pre-recorded.
	Snack 2	Not pre-recorded.
	Dinner 1	Not pre-recorded.
	Dinner 2	Not pre-recorded.
	Store Closed	Thank you for your visit, but we are currently closed. Please visit us again during our normal business hours.
	Pull Forward *	Hello, please pull forward to the next speaker. Thanks. * (Tandem drive-thru only)
REMINDER	Hand Washing	Please wash your hands.
	Sanitizer	Please change sanitizer solution.
	DR Trash	Please check the dining room trash.
	HAACP	Please complete the HAACP shift checklist.
	Quality Check	Please complete the shift quality check.
	Lot Check	Please complete a parking lot check.
	Restroom Check	Please check the restrooms.
	Pre-Rush	Please complete the pre-rush tasks for your workstation.
	Post-Rush	Please complete the post-rush tasks for your workstation.
	Headset Status	To check headset status, press and hold A2 and volume down while turning on the power.
	Change Language	To change headset prompt language, press and hold A1 and volume down while turning on the power.
	Hands Free ON	To turn headset hands free mode on, press and hold B and volume up while turning on the power.
ALERT	Empty 1-3	Not pre-recorded.
	Freezer Door	The freezer door has been left open.
	Cooler Door	The cooler door has been left open.
	Back Door	The back door has been left open.
	Lobby Door	A guest has entered the lobby.
	Empty 1	Not pre-recorded.
Empty 2-16	Not pre-recorded.	

Customer Message Settings

To set up the time periods and locations for Customer Messages to be played, or to name and/or record Customer Messages, press the **Menu** button on the base station **STATUS** display and then, on the **MAIN MENU** press the **Message Center** button.



Press the **Customer Greeter** button on the **MESSAGE CENTER MENU**.




To select a message on the **CUSTOMER MESSAGES** display, press the **Up** or **Dn** button to scroll up or down to highlight the desired message.

To edit a message, select the message and press the **Edit** button.

Rename Message

To change the name of the selected message, press the **Rename** button on the **EDIT CUSTOMER MESSAGE** display.




On the **RENAME MESSAGE** display, use the **Left** and **Right** buttons to move the highlight to a letter or number in the **Name** field that you would like to change, or press the **Clear All** button to delete/replace the entire name. Use the **Up** and **Dn** buttons to enter letters or numbers in the highlighted box, and use the **Right** button to move the box to the next position. When you are finished, press the **Back** button to save the new name.

NOTE:

If you begin editing a name using the **Up** button, you will go through all of the capitalized alphabet, followed by numbers and then lower case alphabet. Using the **Dn** button, the characters will appear in reverse order. Each time you move the highlight to another position, the **Up** or **Dn** button will take you to the next character in sequence, following the last character you entered.

Turn Message On/Off

To turn the selected message on or off, press the **Message** button on the **EDIT CUSTOMER MESSAGE** display to highlight either **On** or **Off**. Press the **Back** button to save this setting.



Review or Record Message


To review the existing selected message, or to record a new message, press the **Review-Record** button on the **EDIT CUSTOMER MESSAGE** display.




NOTE:

Reviewed messages are played to all headsets. Messages may be reviewed only when no vehicles are present.

To listen to the existing message, press the **Review** button on the **REVIEW/RECORD MESSAGE** display. The message will be played in all headsets, and **REVIEWING MESSAGE...** will appear briefly on the display.




To record a new message, press the **Record** button on the **REVIEW/RECORD MESSAGE** display.



Follow the instructions under **READY TO RECORD** on the display. After pressing the headset **B** button, you will have up to 16 seconds to record a message. The **Progress** indicator will show you how much time you have left. When you finish recording, press the **Back** button to save the new message.

Message Schedule


To choose the schedule for the selected message, press the **Schedule** button on the **EDIT CUSTOMER MESSAGE** display.



Press the button for the day on the **SCHEDULE CUSTOMER MESSAGE** display in which you want to select the schedule when the selected message will be played.

NOTE:

To edit the **Start** and **Stop** times for the time periods listed on the **SELECT SCHEDULE TIMES** display, go to the **MESSAGE CENTER MENU** and select **Edit Schedule Times**.




To turn the message on or off for any time period in the day, use the **Up** and **Dn** buttons to scroll through the 12 available time periods. When the desired time period is highlighted, press the **On/Off** button.

On the **EDIT ON/OFF** display, press the **Scheduled** button to turn the message on or off for the selected time period. If you want the message to be on or off during this time period every day, press the **Apply to all days** button to select **Yes**. If **No** is selected, only the selected day will be affected by this change. Press the **Back** button to save this setting.

Message Playback Settings

To edit where the selected Customer message will be heard, press the **Settings** button on the **EDIT CUSTOMER MESSAGE** display.




On the **EDIT CUSTOMER SETTINGS** display, press the button corresponding to the location where you would like the selected message to be heard or not heard, to highlight **On** or **Off**.

If you select **Hear Customer: On**, you will hear a customer at the speaker post, together with the selected Customer message. If you select **Hear Customer: Off**, you will only hear the customer after the message playback has completed.

The **Hear in Headsets** and **Hear in Ceiling** speaker settings allow you to choose whether or not to hear the selected Customer message in those locations.

If you would like a delay after the Customer message is triggered until it begins playing, use the **Up** and **Dn** buttons to change the number in the highlighted box, and use the **Left** or **Right** button to move the highlight to the opposite position.




When you are finished, press the **Back** button to save the setting.

NOTE:

Customer messages are always directed to the drive-thru speaker, regardless of other settings. If the message is turned off, it will not be heard at the speaker.

Reminder Message Settings

To set up the time periods and locations for Reminder Messages to be played, or to name and/or record Reminder Messages, press the **Menu** button on the base station **STATUS** display and then, on the **MAIN MENU** press the **Message Center** button.




Press the **Reminders** button on the **MESSAGE CENTER MENU**.



To select a message on the **REMINDER MESSAGES** display, press the **Up** or **Dn** button to scroll up or down to highlight the desired message. To edit a message, select the message and press the **Edit** button.

Rename Message

To change the name of the selected message, press the **Rename** button on the **EDIT REMINDER MESSAGE** display.



On the **RENAME MESSAGE** display, use the **Left** and **Right** buttons to move the highlight to a letter or number in the **Name** field that you would like to change, or press the **Clear All** button to delete/replace the entire name. Use the **Up** and **Dn** buttons to enter letters or numbers in the highlighted box, and use the **Right** button to move the box to the next position. When you are finished, press the **Back** button to save the new name.

NOTE:

If you begin editing a name using the **Up** button, you will go through all of the capitalized alphabet, followed by numbers and then lower case alphabet. Using the **Dn** button, the characters will appear in reverse order. Each time you move the highlight to another position, the **Up** or **Dn** button will take you to the next character in sequence, following the last character you entered.

Turn Message On/Off

To turn the selected message on or off, press the **Message** button on the **EDIT REMINDER MESSAGE** display to highlight either **On** or **Off**. Press the **Back** button to save this setting.




Review or Record Message


To review the existing selected message, or to record a new message, press the **Review-Record** button on the **EDIT REMINDER MESSAGE** display.

NOTE:


Reviewed messages are played to all headsets. Messages may be reviewed only when no vehicles are present.



To listen to the existing message, press the **Review** button on the **REVIEW/RECORD MESSAGE** display. The message will be played in all headsets, and **REVIEWING MESSAGE...** will appear briefly on the display.



To record a new message, press the **Record** button on the **REVIEW/RECORD MESSAGE** display.



Follow the instructions under **READY TO RECORD** on the display. After pressing the headset **B** button, you will have up to 10 seconds to record the message. The **Progress** indicator will show you how much time you have left. When you finish recording, press the **Back** button to save the new message.

NOTE:

If a low priority reminder message is scheduled to be played when communication with a customer is ongoing, the message will be cancelled. If a high priority reminder message is scheduled to be played when communication with a customer is ongoing, the message will be played after communication with the customer ends.


Message Priority

To set a priority selected message, press the **Priority** button on the **EDIT REMINDER MESSAGE** display to highlight either **High** or **Low**. Press the **Back** button to save this setting.



Message Schedule


To choose the schedule for the selected message, press the **Schedule** button on the **EDIT REMINDER MESSAGE** display.



Press the button for the day on the **SCHEDULE REMINDER MESSAGE** display in which you want to select the schedule when the message will be played.

NOTE:

To edit the **Start** and **Stop** times for the time periods listed on the **SELECT SCHEDULE TIMES** display, go to the **MESSAGE CENTER MENU** and select **Edit Schedule Times**.




To turn the message on or off for any time period in the day, use the **Up** and **Dn** buttons to scroll through the 12 available time periods. When the desired time period is highlighted, press the **On/Off** button.


On the **EDIT ON/OFF** display, press the **Scheduled** button to turn the message on or off for the selected time period. If you want the message to be on or off during this time period every day, press the **Apply to all days** button to select **Yes**. If **No** is selected, only the selected day will be affected by this change. Press the **Back** button to save this setting.

Message Playback Settings

To choose where the selected Reminder message will be heard, press the **Settings** button on the **EDIT REMINDER MESSAGE** display.



To designate specific headsets where you would like the selected Reminder message to be heard, press the **Headsets** button on the **EDIT REMINDER SETTINGS** display.



NOTE:

By default, messages play to all headsets.

On the **SELECT REMINDER HEADSETS** display, use the **Up** and **Dn** buttons to select a headset number for which you would like to turn the selected Reminder message on or off, and then press the **Edit** button.

To turn the message on or off in the selected headset, press the **Turn Headsets** button on the **EDIT ON/OFF** display to highlight **On** or **Off**. To turn the message on or off in all headsets, press the **Apply to all headsets?** button to highlight **Yes** or **No**.

Press the **Back** button twice to return to the **EDIT REMINDER SETTINGS** display.



NOTE:

After selecting **On**, to hear the Reminder message in the Ceiling Speaker or Line Out, you must also be sure their volume is set high enough for the message to be audible. To do this, return to the **MAIN MENU** and select **Volume Adjust**, and follow the instructions under **Volume Adjustments**.


To have the selected Reminder message heard in the ceiling speaker(s), or not heard, press the **Hear In Ceiling Speaker** button to highlight **Off** or **On**.

To have the selected Reminder message heard in the line out(s), or not heard, press the **Hear In Line Out** button to highlight **Off** or **On**.


To have the Reminder message repeated at selected intervals, press the **Repeat** button on the **EDIT REMINDER SETTINGS** display, and use the **Left** or **Right** button to move the highlight left or right for hours, minutes or seconds (HH:MM:SS) in the **Time** field, and use the **Up** and **Dn** buttons to change the number in the highlighted box. When you are finished, press the **Back** button to save the setting.

Alert Message Settings

To set up the time periods and locations for Alert Messages to be played, or to name and/or record Alert Messages, press the **Menu** button on the base station **STATUS** display and then, on the **MAIN MENU** press the **Message Center** button.




Press the **Alerts** button on the **MESSAGE CENTER MENU**.



To select a message on the **ALERT MESSAGES** display, press the **Up** or **Dn** button to scroll up or down to highlight the desired message. To edit a message, select the message and press the **Edit** button.

Rename Message

To change the name of the selected message, press the **Rename** button on the **EDIT ALERT MESSAGE** display.



On the **RENAME MESSAGE** display, use the **Left** and **Right** buttons to move the highlight to a letter or number in the **Name** field that you would like to change, or press the **Clear All** button to delete/replace the entire name. Use the **Up** and **Dn** buttons to enter letters or numbers in the highlighted box, and use the **Right** button to move the box to the next position. When you are finished, press the **Back** button to save the new name.

NOTE:

If you begin editing a name using the **Up** button, you will go through all of the capitalized alphabet, followed by numbers and then lower case alphabet. Using the **Dn** button, the characters will appear in reverse order. Each time you move the highlight to another position, the **Up** or **Dn** button will take you to the next character in sequence, following the last character you entered.

Turn Message On/Off

To turn the selected message on or off, press the **Message** button on the **EDIT ALERT MESSAGE** display to highlight either **On** or **Off**. Press the **Back** button to save this setting.



Review or Record Message


To review the existing selected message, or to record a new message, press the **Review-Record** button on the **EDIT ALERT MESSAGE** display.

NOTE:


Reviewed messages are played to all headsets. Messages may be reviewed only when no vehicles are present.



To listen to the existing message, press the **Review** button on the **REVIEW/RECORD MESSAGE** display. The message will be played in all headsets, and **REVIEWING MESSAGE...** will appear briefly on the display.




To record a new message, press the **Record** button on the **REVIEW/RECORD MESSAGE** display.




Follow the instructions under **READY TO RECORD** on the display. After releasing the **B** button, you will have up to 10 seconds to record the message. The **Progress** indicator will show you how much time you have left. When you finish recording, press the **Back** button to save the new message.

Message Schedule

To choose the schedule for the selected message, press the **Schedule** button on the **EDIT ALERT MESSAGE** display.




Press the button for the day on the **SCHEDULE ALERT MESSAGE** display in which you want to select the schedule when the selected message will be played.



To turn the message on or off for any time period in the day, use the **Up** and **Dn** buttons to scroll through the 12 available time periods. When the desired time period is highlighted, press the **On/Off** button.

NOTE:

To edit the **Start** and **Stop** times for the time periods listed on the **SELECT SCHEDULE TIMES** display, go to the **MESSAGE CENTER MENU** and select **Edit Schedule Times**.




On the **EDIT ON/OFF** display, press the **Scheduled** button to turn the message on or off for the selected time period. If you want the message to be on or off during this time period every day, press the **Apply to all days** button to select **Yes**. If **No** is selected, only the selected day will be affected by this change.


To save these settings, press the **Back** button one or more times.

Message Playback Settings

To choose where the selected Alert message will be heard, press the **Settings** button on the **EDIT ALERT MESSAGE** display.



To designate specific headsets where you would like the selected Alert message to be heard, press the **Headsets** button on the **EDIT ALERT SETTINGS** display.




NOTE:

By default, messages play to all headsets.

On the **SELECT ALERT HEADSETS** display, use the **Up** and **Dn** buttons to select a headset number for which you would like to turn the selected Alert message on or off, and then press the **Edit** button.


To turn the message on or off in the selected headset, press the **Turn Headsets** button on the **EDIT ON/OFF** display to highlight **On** or **Off**. To turn the message on or off in all headsets, press the **Apply to all headsets?** button to highlight **Yes** or **No**, and press the **Back** button.



To have the selected Alert message heard in the ceiling speaker(s), or not heard, press the **Hear In Ceiling Speaker** button to highlight Off or On.


To have the selected Alert message heard in the line out(s), or not heard, press the **Hear In Line Out** button to highlight Off or On.

To set a delay after the Alert message is triggered until it begins playing, press the **Delay** button.



On the **DELAY BEFORE PLAY** display, use the **Left** or **Right** button to move the highlight left or right in the **Delay** field for minutes and seconds (MM:LL).

To have the Alert message repeated at selected intervals, press the **Repeat** button.




On the **REPEAT INTERVAL** display, use the **Left** or **Right** button to move the highlight left or right in the **Time** field for hours, minutes or seconds (HH:MM:SS).

Use the **Up** and **Dn** buttons to change the number in the highlighted box.

To save these settings, press the **Back** button one or more times.

Schedule Times

To set up all the time periods during each day, in which all Message Center messages can be scheduled, press the **Menu** button on the base station **STATUS** display and then, on the **MAIN MENU** press the **Message Center** button.



Press the **Edit Schedule Times** button on the **MESSAGE CENTER MENU**.




There are 12 possible time periods. To select a time period to be edited, use the **Up** and **Dn** buttons to scroll through the 12 available time periods. When the desired time period is highlighted, press the **Edit** button.

On the drop-down **EDIT SCHEDULE TIMES** display, to edit the Start or Stop time, use the **Left** and **Right** buttons to move the highlight in the **Start** or **Stop** field, and use the **Up** and **Dn** buttons to change the highlighted numbers. To move from one field to the other, repeat pressing the **Left** or **Right** button until the highlight moves from one field to the other.

NOTE:

Times are in 24 hour format.
example:
 0500 = 5 A.M.
 1700 = 5 P.M.
 0000 = Midnight



To save these settings, press the **Back** button one or more times.


Volume Adjustments

To adjust the volume of inbound and outbound audio, alert tones and message repeater messages, on the base station **STATUS** display, select **Menu** and then, on the **MAIN MENU** select **Volume Adjust**.

Press the buttons on the left side of the **VOLUME MENU** to select where you want to adjust the volume.

NOTE:



If you have a dual lane operation, the **VOLUME MENU** will have the same selections for **Lane 1** and **Lane 2** as shown here on the **VOLUME MENU**. Make your selections accordingly.





On the next display that appears for the selected location, press the button next to the volume you would like to adjustment, and then use the **Up** and **Dn** buttons to raise and lower the volume.

NOTE:

IN/OUTBOUND VOLUME settings adjust the level to and from the outside speaker/microphone and the level of the outbound message from the Message Center.



VEHICLE TONE VOLUME setting only adjusts the level of the alert tone heard in the headset.



To save these settings, press the **Back** button one or more times.

Wired Backup System Operation

In order to use a Wired Backup System, you must have a Switcher Board (optional) in your base station. If you have a Switcher Board, you will find a switch on the bottom of your base station as shown in Figure 10.

If you have a single lane drive-thru operation, you will find one switch in the **Lane 1** position

If you have a dual lane drive-thru operation, you may have two Switcher Boards in your base station, in which case you will find two switches on the bottom of your base station, one for **Lane 1** and another for **Lane 2**.

- To use the Wired Backup System, place the switch for **Lane 1** and/or **Lane 2** in the **Backup** (In) position.
- When you have finished using the Wired Backup System, return the switch to the **Wireless** (Out) position.





Figure 10. Wired backup switches on bottom of base station

Vehicle Detection


You can test the vehicle detector function by simulating a vehicle arrival at the speaker post or menu board.

Before doing this, be sure there is no car (or metal object) at the detection point.


Press the **Menu** button on the base station **STATUS** display and then press the **Vehicle Detection** button on the **MAIN MENU**.



On the **VEHICLE DETECTION** display, press the **Mode** button to select **Override**. This will cause the vehicle alert tone to be played in headsets, followed by inbound audio from the outside speaker. To return to normal operation, press the **Mode** button again to select **Normal**.



If you have a Vehicle Detector Board (VDB) in your base station, and you experience a problem with vehicle detection, such as the inbound audio not shutting off from the outside speaker or no alert tone when a vehicle arrives, you can reset the Vehicle Detector by pressing the **Reset Detector** button on the **VEHICLE DETECTION** display, and then pressing the **Yes** button.



Press the **Back** button one or more times after **Reset Completed** appears and disappears on the display.


Store Settings

Store settings are crucial to drive-thru operation, and are normally controlled by password access.


To access Store Settings, press the **Menu** button on the base station **STATUS** display and then press the **More** button on the **MAIN MENU**.

NOTE:

Store settings are normally made or changed only by authorized personnel such as store managers. Making changes to store settings may require a password.



On the **ADVANCED MENU**, press the **Store Settings** button.




User Password

NOTE:

*To set a password for the first time, press the **Set Password** button on the **STORE SETTINGS** display and follow the instructions under [Change Password](#).*


To make changes to store settings, you may need a password. If you do, the **ENTER USER PASSWORD** display will appear. If you do not need a password, the **STORE SETTINGS** display will appear immediately.

If you have a password, use the **Left** and **Right** buttons to move the highlighted box in the **Enter Password** field, and use the **Up** button to put alphabetic characters in the box, or the **Dn** button to put numeric characters in the box. Each time you have entered a character of your password, press the **Right** button to move the highlighted box to the next position and enter the next character. If you want to start over with a new number, press the **Clear All** button. After entering your entire password, press the **Continue** button to view the **STORE SETTINGS** display. To view additional **ADVANCED STORE SETTINGS**, press the **More** button.




Set Date or Time

To make changes to the date or time settings, press the **Set Date** or **Set Time** button on the **STORE SETTINGS** display.



Use the **Left** and **Right** buttons to move the highlight in the **Date** or **Time** field, and use the **Up** and **Dn** buttons to change the highlighted numbers.




To save these settings, press the **Back** button one or more times.

HINT!


When setting the time, set it a little in advance of the known correct time and then, when the correct time matches the setting, press the **Back** button to restart the clock.

Set Store Hours

To make changes to the store hours for any day, press the **Set Store Hours** button on the **STORE SETTINGS** display.




Press the button of the day you would like to change. Use the **Left** and **Right** buttons to move the highlight in the **Open** or **Close** field, and use the **Up** and **Dn** buttons to change the highlighted numbers. To move from one field to the other, repeat pressing the **Left** or **Right** button until the highlight moves from one field to the other. If you want these store hours to apply to every day, press the **Copy** button and then press the **Apply to all days?** button to highlight **Yes**.



To save these settings, press the **Back** button one or more times.

Edit Schedule Times

Up to 12 Schedule Times can be set to establish periods in which messages can be played from the Message Center. Schedule Times can be edited as needed. To make changes to the Schedule Times, press the **Edit Schedule Times** button on the **STORE SETTINGS** display.




On the **EDIT SCHEDULE TIMES** display, press the **Up** or **Dn** buttons to move up and down the list of time periods. You can continue pressing the **Dn** button past 7 until you reach 12.

NOTE:

The **EDIT SCHEDULE TIMES** display can also be accessed through the **MESSAGE CENTER**.



When the time period you would like to change is highlighted, press the **Edit** button.



NOTE:


If your store is open 24 hours, set the **Stop** time the same as the **Start** time.

Use the **Left** and **Right** buttons to move the highlight in the **Start** or **Stop** field, and then use the **Up** and **Dn** buttons to change the highlighted numbers. To move from one field to the other, repeat pressing the **Left** or **Right** button until the highlight moves beyond the end of one field and into the other.

To save these settings, press the **Back** button one or more times.

Change Password


For security purposes, you may need to change the password periodically for entry to the **STORE SETTINGS** display, or when someone's employment terminates. To do this, press the **Set Password** button on the **STORE SETTINGS** display. The current password will be shown in the **Enter New Password** field on the **SET USER PASSWORD** display.



Use the **Left** and **Right** buttons to move the highlighted box in the **Enter New Password** field. Use the **Up** button to put alphabetic characters in the highlighted box, or the **Dn** button to put numeric characters in the highlighted box. Continuing down from A will take you to numeric characters. Continuing up from 9 will take you to alphabetic characters. Press the **Right** button to move the highlighted box to the next position and enter the next character. If you want to start over with a new number, press the **Clear All** button. After entering the entire new password, press the **Back** button twice to save the new password and return to the **ADVANCED MENU**.

Phone Headsets

If there is an HME Telephone Interface connected to your base station, you can assign one beltpac/headset to receive incoming telephone calls. To do this, press the **Phone Headset** button on the **STORE SETTINGS** display. Use the **Left** and **Right** buttons to move the highlight in the **Select Phone Headset** field, and then use the **Up** and **Dn** buttons to enter number of the beltpac/headset.




To save these settings, press the **Back** button one or more times.

VAA Adjustment


VAA settings can be adjusted to eliminate echo, feedback or fluctuating inbound audio levels.

To adjust VAA levels, press the **More** button on the **STORE SETTINGS** display. On the **ADVANCED STORE SETTINGS** display, press the **VAA** button.



NOTE:

If you have a dual lane drive-thru operation, you may need to make this adjustment for each lane.



VAA On or Off:

To turn the VAA feature on or off, press the **VAA** button to select **On** or **Off**.

VAA Sensitivity Level:


This is the volume level of the order taker's voice required to activate the VAA circuit. If speaking to the customer does not automatically reduce the inbound level, press the **VAA Sensitivity** button and then press the **Up** and **Dn** buttons until the inbound audio is reduced while you are speaking to the customer, and returns to normal when you stop speaking.

VAA Attenuation Level:

This is the amount that the inbound volume level is reduced when the order taker speaks to the customer. If the order taker cannot hear the inbound audio at all while speaking, the **VAA Attenuation** can be adjusted to a lower level. To adjust the inbound level while the order taker is speaking, press the **VAA Attenuation** button and then press the **Up** and **Dn** buttons until the desired level is reached.


Restore Installer Settings

To delete all of your custom settings and return to the original settings made by the ion|IQ™ installer, press the **Restore Installer Settings** button on the **ADVANCED STORE SETTINGS** display, and then press the **Restore** button on the **RESTORE INSTALLER DEFAULTS** display.



Network Settings

If your base station is connected to a computer network, the network settings were set up by the ion|IQ™ installer. If you need to contact HME Technical Support regarding any problem with your network connection, you may be asked to make changes to the network settings. If so, press the **More** button on the **STORE SETTINGS** display. On the **ADVANCED STORE SETTINGS** display, press the **Network Settings** button.



On the **NETWORK SETTINGS** display, make the selection requested by the HME Technical Support representative, and then make any changes you are instructed to make.

For example; You may be asked to select the IP Address. On the **EDIT IP ADDRESS** display, you can use the **Left** and **Right** buttons to move the highlighted box left and right in the **Address** field. Use the **Up** and **Dn** buttons to change the numbers in the highlighted box. After entering the new Address, press the **Back** button to save the entry and return to the **NETWORK SETTINGS** display.

NOTE:


The **EDIT IP ADDRESS** display is shown here as an example. However, the method of editing each of the network settings is the same.



Automatic Volume Control

When the Automatic Volume Control (AVC) is on, the volume level at the outside microphone will be automatically adjusted to compensate for environmental noise at the speaker post. When there is excessive noise, the level of the order taker's voice in the speaker will be adjusted up. When it is quiet in the drive-thru area, the level will be adjusted down.

To turn the Automatic Volume Control on or off, press the **More** button on the the **STORE SETTINGS** display, and then press the **AVC** button on the **ADVANCED STORE SETTINGS** display to select **On** or **Off**.




LCD Contrast

To adjust the light/dark contrast of the base station display, press the **More** button on the **STORE SETTINGS** display. On the **ADVANCED STORE SETTINGS** display, press the **LCD Contrast** button and then press the **Up** (lighter) and **Dn** (darker) buttons to adjust the contrast. When you are finished, press the **Back** button as needed to save the setting and return to the desired display.

NOTE:

The LCD contrast is set at the factory, and will normally not need to be adjusted.




PC Navigation

If your ion|IQ™ was set up to operate with a PC network, all of the same settings that can be made on the base station can also be made on your PC.

The following examples show you how to navigate through system settings as they appear on your PC screen.


To open the ion|IQ™ on your PC, enter its IP Address in the address bar on your internet browser as shown below, and then press the **Enter** key.




NOTE:

To find the IP Address, go through the following display path on your base station – **STATUS > Menu, MAIN MENU > More, ADVANCED MENU > Store Settings, STORE SETTINGS > More, ADVANCED STORE SETTINGS > Network Settings**

Select any topic from the **Main Menu** that you would like to view or edit. Some topics will cause a **Secondary Menu** bar to appear, from which you can select a sub-topic.



If you click your cursor on an **Edit** button, an edit bar will appear with setup choices. If you make any setup changes, you must click on the **Save** button to save your changes. If you do not want to save your changes, or do not make any changes, you can click on any other menu topic, or click on the back arrow at the top-left corner of the browser screen.



EQUIPMENT CARE AND CLEANING

Handling the Equipment Properly

- When adjusting the position of the headset microphone, hold the boom at its base, not at the microphone end.
- Carry the headset by the headband, not by the earpiece, and never by the microphone boom.
- Use both hands to put the headset on or take it off.

Cleaning the Equipment

COM6000BP

- Remove the battery.
- Clean the battery and headset with a damp sponge sprayed with household cleaner. Squeeze excess liquid out of the sponge before using it.
- Clean the metal battery contacts on the battery and headset as follows. Wet the tip of a swab with alcohol and squeeze the excess alcohol from it. Wipe each contact with the swab and be certain all the contacts are dry before reinstalling the batteries.
- Foam muffs on headset earpieces can easily be replaced for sanitary purposes. To order extra foam muffs, call your local HME sales representative.

Battery Charger

Avoid splashing water or grease on the battery charger. Clean the battery charger monthly as follows.

- Remove all batteries from the battery charger.
- Clean the battery charger case with a damp sponge. Wet the sponge and wring it out so it is damp, not dripping wet. Spray household cleaner on the sponge (NOT DIRECTLY ON THE EQUIPMENT). Clean the battery charger with the sponge and dry it thoroughly.

Wet the tip of a cotton swab with rubbing alcohol and squeeze the excess alcohol from the swab. Wipe the metal contacts inside each battery port with the damp swab. Allow the contacts to dry before placing batteries in the ports.

CAUTION:
Always unplug the battery charger before cleaning it.

IN CASE OF PROBLEMS


Troubleshooting

PROBLEM	PROBABLE CAUSE	SOLUTION
“Battery failed” is heard in headset when PWR button is pressed.	Battery may be defective.	Replace battery. Call HME.*
“Headset failed” is heard in headset when PWR button is pressed.	Headset may be defective.	Use another headset. Call HME.*
You hear your echo in headset earpiece when you speak into headset microphone.	Outside speaker and microphone may not be properly installed.	Be sure speaker and microphone are isolated from each other, and are tightly mounted with enough foam packed around each of them to absorb vibrations.
	Outbound and/or inbound audio level may be set too high.	Set outbound audio level just high enough to be heard by customers. Lower inbound audio to comfortable level.
	VAA level may need to be adjusted.	Adjust VAA level to reduce inbound audio level when you are speaking into the headset microphone.
		Adjust VAA attenuation level to reduce inbound audio level when you are speaking into the headset microphone. NOTE: If the inbound level is too low, you will not hear the customer.
No sound is heard in headset when you press button A and speak into microphone.	Power may be off at base station.	Be sure HME logo and other lights on base station are lit. Check circuit breaker for building.
	Power supply in base station may not be working.	Be certain power adapter is plugged into AC electrical outlet, and is connected to J3 on base station audio circuit board.
	Headset power may not be on.	Press PWR button on headset. Be certain power light goes on and switches from red to green.
	Volume may not be set correctly.	Adjust volume with Volume-up and down buttons.
	Battery may be low or defective.	Check Power light. If not lit, replace battery.
	Headset may be defective.	Use another headset. Call HME.*
	Headset may not be registered.	Register headset.
Channel A or B is not working.	Headset power may not be on.	Press PWR button on headset. Be certain power light goes on and switches from red to green.
	Battery may be low or defective.	Check Power light. If not lit, replace battery.
	A1/A2 or B1/B2 light on base station does not light when headset button A or B is pressed.	Use another headset. Call HME.*
	Headset may not be registered.	Register headset.
Outbound sound is too low.	Outbound volume may be set too low for environment.	Adjust outside speaker volume level.
No outbound sound; Customer cannot hear anything.	System may be set for speed team.	Check speed-team setting.
	There may be loose wires on outside speaker or base station circuit board.	Check vehicle present light (car) on base station. Check outside speaker wire connections on J6 or J14 in base station and at outside speaker.
	Defective speaker or base station.	Call HME.*

PROBLEM	PROBABLE CAUSE	SOLUTION
Customer cannot be heard in push-to-talk (PTT) operation.	System may be set for speed team.	Check speed-team setting.
	Base station may be set for wrong drive-thru mode (full or half-duplex).	Check drive-thru mode setting.
Only intermittent voice can be heard in headsets.	Transmitter antenna connectors on base station transceiver circuit board may be loose or damaged.	Be certain antennas are screwed securely onto base station. Check transmitter antenna cable connection at ANT1 and ANT2 on left side of transceiver circuit board. Call HME.*
	Circuit board may be defective.	Call HME.*
	VAA level is too sensitive.	Reduce VAA level.
Personnel hear customers in ceiling speaker or headsets, but cannot hear each other.	Circuit board may be defective.	Check to see if A1/A2 and B1/B2 lights on base station are lit when buttons are pressed. Call HME.*
	Headset may be defective.	Use another headset. Call HME.*
No tone or sound is heard in ceiling speaker or headsets when vehicle enters drive-thru lane.	Power interruption may have caused vehicle detection circuit to be out of balance.	When no vehicle is in the drive-thru lane, reset vehicle detector.
	System may be set for speed team.	Check speed-team setting.
	Connector may be loose.	Check all connectors in base station. Call HME.*
Personnel cannot hear customers in ceiling speaker or headsets.	There may be loose wires on base station circuit board.	Check all wire insertions to connectors on base station circuit boards.
	System may be set for speed team.	Check speed-team setting.
	Outside speaker, audio circuit board or vehicle detector board failed.	Call HME.*
	VAA attenuation set too high.	Reduce attenuation.
Headset has intermittent sound.	Battery may be low.	Replace battery.
	Headset may be defective.	Use another headset. Call HME.*
There is still sound in headset after all customers have been served.	Base station may be to override position.	On the VEHICLE DETECTION menu, be certain the Mode setting is in the Normal position.
	Vehicle detector may be locked up.	On the VEHICLE DETECTION menu, select Reset Veh Detect.
Battery charger is not working.	Charger may not be plugged in.	Be certain charger is plugged in. If it still is not working, call HME.*
“Registration failed” message heard in headset. Lights stay red.	Base station power not on.	Be sure HME logo and other lights on base station are lit. If no light is lit, be sure power adapter is plugged into electrical outlet, and is connected to J3 on base station audio circuit board.
	Registration button not pushed.	Repeat registration procedure. Call HME.*

Service Call

- For information to contact HME Technical Support, select **Menu** on the base station * **STATUS** display and then select **Service** on the **MAIN MENU**, or press the **Help** button under the display screen.



Base Station Internal Controls and Indicators





Figure 11. Base station internal features

1. ANT1 antenna connector
2. ANT2 antenna connector
3. Jumper, microphone load, JP1-Lane 1
4. Jumper, microphone load, JP2-Lane 2
5. Switcher board connectors, J4-Lane 1
6. Switcher board connectors, J13-Lane 2
7. Ethernet connector, J12
8. Power connector, J3
9. Ceiling speaker connector, J1-Lane 1, J11-Lane 2
10. Outside speaker/microphone connector, J6-Lane 1, J14-Lane 2
11. Line in/out connector, J7-Lane 1, J16-Lane 2
12. Early warning/alert connector, J9-Lane 1, J19-Lane 2
13. Remote switch connector, J2
14. Reset switch
15. Telephone connector, J15
16. Doors connector, J5
17. Vehicle detector board (VDB) connector, J10-Lane 1, J20-Lane 2

Diagnostics

If you make a service call to HME Technical Support, you may be asked to have diagnostics performed automatically by the base station. If so, select **Menu** on the base station **STATUS** display and then press the **More** button on the **MAIN MENU**.



On the **ADVANCED MENU**, press the **Diagnostics** button, and then select the test requested by the Technical Support representative. If requested, press the **More** button for additional advanced diagnostics.



EQUIPMENT SPECIFICATIONS

Base Station

Voltage input	24VDC \pm 2.5V
AC current input	2.5A maximum
Audio distortion	5% maximum level
Outside speaker output	3 watts RMS into 8 ohms
Ceiling speaker power	3 watts RMS into 8 ohms
TX/RX frequency	2400MHz – 2483.5MHz
Dimensions	9.75”H x 13”W x 3.5”D (248 mm x 330 mm x 89 mm)
Weight	3.25 lbs (1.47 kg) maximum

COM6000BP

Battery type	3.6V Lithium ion
Battery life	18 - 20 hours (typical)
RF frequency	2400MHz – 2483.5MHz
Weight	5.1 oz (.133 kg) with battery

Odyssey IQ All-In-One Headset

Battery type	3.6V Lithium ion
Battery life	18 - 20 hours (typical)
RF frequency	2400MHz – 2483.5MHz
Weight	5.7 oz (.16 kg) with battery

AC40 Battery Charger

Voltage input	16.5VAC
Charging time	2 hrs maximum
Dimensions	7.6” x 4.6” x 2.6” (193mm x 117mm x 66mm)
Weight	1.5 lb (.68 kg)

FCC NOTICE

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.

NOTE: This equipment has been tested and found to comply with the limits for a Class A digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communication. Operation of this equipment in a residential area is likely to cause harmful interference, in which case the user will be required to correct the interference at his own expense.

Changes or modifications not expressly approved by HM Electronics, Inc. could void the users authority to operate this equipment.

The antenna(s) used for the base transmitter must be installed to provide a separation distance of at least 20 cm from all persons and must not be co-located or operating in conjunction with any other antenna or transmitter.

This device has been designed to operate with the antennas or antenna kits listed below, and having a maximum gain of 2dBi. Antennas/Kits not included in this list or having a gain greater than 2dBi are strictly prohibited for use with this device. The required antenna impedance is 50 ohms.

1. Antenna: NEARSON, S181TR-2450R, 2dBi
2. Antenna Kit: HME, EC20 (P/N G28493-1), 0dBi
3. Antenna Kit: HME, EC10 (P/N G27706-1)

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

Hereby, HM Electronics, Inc. declares that the ion|IQ™ is in compliance with the essential requirements and other relevant provisions of R&TTE Directive 1999/5/EC.



This product operates in the 2400 to 2483.5 MHz frequency range. The use of this frequency range is not yet harmonized between all countries. Some countries may restrict the use of a portion of this band or impose other restriction relating to power level or use. You should contact your Spectrum authority to determine possible restrictions.

IMPORTANT!

Waste Electrical and Electronic Equipment (WEEE)

The European Union (EU) WEEE Directive (2002/96/EC) places an obligation on producers (manufacturers, distributors and/or retailers) to take-back electronic products at the end of their useful life. The WEEE Directive covers most HME products being sold into the EU as of August 13, 2005. Manufacturers, distributors and retailers are obliged to finance the costs of recovery from municipal collection points, reuse, and recycling of specified percentages per the WEEE requirements.

Instructions for Disposal of WEEE by Users in the European Union

The symbol shown below is on the product or on its packaging which indicates that this product was put on the market after August 13, 2005 and must not be disposed of with other waste. Instead, it is the user's responsibility to dispose of the user's waste equipment by handing it over to a designated collection point for the recycling of WEEE. The separate collection and recycling of waste equipment at the time of disposal will help to conserve natural resources and ensure that it is recycled in a manner that protects human health and the environment. For more information about where you can drop off your waste equipment for recycling, please contact your local authority, your household waste disposal service or the seller from whom you purchased the product.



HME ion|IQ™ Message Center Quick Start Guide

Right Message, Right People, Right Time!

INSTRUCTIONS

Planning to set-up your HME ion|IQ™ Message Center is easy to do when you follow these three simple steps.

STEP ONE: Choose your CUSTOMER GREETINGS, EMPLOYEE REMINDERS, and ALERTS

TIP: Schedule only a few messages at a time and change them often to improve your customers' and employees' awareness. Choose from several common messages provided in your HME ion|IQ™, or record your own unique messages. (See **Page 16** in your ion|IQ™ Operating Instructions manual for a list of pre-programmed messages.)

- ❖ 3 or 4 CUSTOMER GREETINGS that play to your customers when they arrive at the menu board
- ❖ 2 or 3 REMINDERS that play to your employees to remind them of important tasks such as hand washing
- ❖ 1 or 2 ALERTS that notify the employees when something needs immediate attention such as when the back door is left open

STEP TWO: Determine WHEN and WHERE the messages play

- ❖ CUSTOMER GREETINGS play through the speaker at the menu board. REMINDERS and ALERTS are played through any or all headsets and/or grill speaker. Playing REMINDER and ALERT messages to ALL headsets is the default setting and is most commonly used
- ❖ A REPEAT time can be set when a REMINDER is to be played throughout the day. For example, repeat every 60 minutes for the task reminder of hand washing
- ❖ A DELAY can be set for an ALERT when you want to be notified if something has occurred for a specific period of time. For example, alert when the back door has been left open for five minutes.

STEP THREE: Create your message schedule for the messages listed in STEP TWO

- ❖ CUSTOMER GREETINGS can be scheduled to change with your day-part business. For example, schedule one greeting for breakfast, another for lunch and dinner, and a third to promote an all day special.

TIP: A default CLOSED message can play automatically after the store is closed and stops when the store opens. To use this feature, you must make sure the store hours are set correctly. (See **page 35** in your ion|IQ™ Operating Instructions manual.)

- ❖ REMINDERS and ALERTS are commonly scheduled to play ALL DAY and typically use the delay or repeat feature
- ❖ The message SCHEDULE can be customized by day, although it is most commonly the same for every day of the week

HME ion|IQ™ Message Center Quick Start Guide

Right Message, Right People, Right Time!

EXAMPLE PLANNER

CUSTOMER GREETINGS

	NAME	START TIME	STOP TIME
1	BREAKFAST	06:00	11:00
2	LUNCH/DINNER	11:00	20:00
3	DRINK PROMO	06:00	01:00
4			

REMINDERS

	NAME	START TIME	STOP TIME	REPEAT	HEADSETS	GRILL SPKR
1	HAND WASHING	06:00	01:00	1 Hr	ALL	YES
2	CHANGE SANITIZER	06:00	01:00	4 Hr	ALL	YES
3						

ALERTS

	NAME	START TIME	STOP TIME	REPEAT	DELAY	HEADSETS	GRILL SPKR
1	BACK DOOR DAY	06:00	01:00	5 min	5 min	ALL	YES
2	BACK DOOR NIGHT	20:00	01:00	5 min	1 min	ALL	YES
3							

SCHEDULE

	START TIME	STOP TIME	NOTES
1	06:00	11:00 am	Customer Greeting #1
2	11:00	20:00 pm	Customer Greeting #2
3	06:00	01:00 am	Customer Greeting #3, Reminder #1 and #2
4	06:00	20:00 am	Alert #1
5	20:00	01:00 am	Alert #2
6			

NOTE: You can set up to 12 different time schedules.

HME ion|IQ™ Message Center Quick Start Guide

Right Message, Right People, Right Time!

CUSTOMER GREETINGS

	NAME	START TIME	STOP TIME
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

REMINDERS

	NAME	START TIME	STOP TIME	REPEAT	HEADSETS	GRILL SPKR
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						

ALERTS

	NAME	START TIME	STOP TIME	REPEAT	DELAY	HEADSETS	GRILL SPKR
1							
2							
3							
4							

SCHEDULE

	START TIME	STOP TIME	NOTES
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			

HME ion|IQ™ Message Center Quick Start Guide

Right Message, Right People, Right Time!

CUSTOMER GREETINGS

	NAME	START TIME	STOP TIME
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

REMINDERS

	NAME	START TIME	STOP TIME	REPEAT	HEADSETS	GRILL SPKR
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						

ALERTS

	NAME	START TIME	STOP TIME	REPEAT	DELAY	HEADSETS	GRILL SPKR
1							
2							
3							
4							

SCHEDULE

	START TIME	STOP TIME	NOTES
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			

HME ion|IQ™ Message Center Quick Start Guide

Right Message, Right People, Right Time!

CUSTOMER GREETINGS

	NAME	START TIME	STOP TIME
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

REMINDERS

	NAME	START TIME	STOP TIME	REPEAT	HEADSETS	GRILL SPKR
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						

ALERTS

	NAME	START TIME	STOP TIME	REPEAT	DELAY	HEADSETS	GRILL SPKR
1							
2							
3							
4							

SCHEDULE

	START TIME	STOP TIME	NOTES
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			

HME ion|IQ™ Message Center Quick Start Guide

Right Message, Right People, Right Time!

CUSTOMER GREETINGS

	NAME	START TIME	STOP TIME
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

REMINDERS

	NAME	START TIME	STOP TIME	REPEAT	HEADSETS	GRILL SPKR
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						

ALERTS

	NAME	START TIME	STOP TIME	REPEAT	DELAY	HEADSETS	GRILL SPKR
1							
2							
3							
4							

SCHEDULE

	START TIME	STOP TIME	NOTES
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			

HME ion|IQ™ Message Center Quick Start Guide

Right Message, Right People, Right Time!

CUSTOMER GREETINGS

	NAME	START TIME	STOP TIME
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

REMINDERS

	NAME	START TIME	STOP TIME	REPEAT	HEADSETS	GRILL SPKR
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						

ALERTS

	NAME	START TIME	STOP TIME	REPEAT	DELAY	HEADSETS	GRILL SPKR
1							
2							
3							
4							

SCHEDULE

	START TIME	STOP TIME	NOTES
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			

HME ion|IQ™ Message Center Quick Start Guide

Right Message, Right People, Right Time!

CUSTOMER GREETINGS

	NAME	START TIME	STOP TIME
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			

REMINDERS

	NAME	START TIME	STOP TIME	REPEAT	HEADSETS	GRILL SPKR
1						
2						
3						
4						
5						
6						
7						
8						
9						
10						

ALERTS

	NAME	START TIME	STOP TIME	REPEAT	DELAY	HEADSETS	GRILL SPKR
1							
2							
3							
4							

SCHEDULE

	START TIME	STOP TIME	NOTES
1			
2			
3			
4			
5			
6			
7			
8			
9			
10			
11			
12			